

AIRMAX

Installation Instructions

(1999-2003 S/T-10 Pick-up /Blazer 2.2L Part # 12200)

Important! Read all instructions before you begin installation.

1. Unclamp and remove air inlet hose from factory air cleaner assembly. Remove factory air cleaner assembly. Remove slide bracket that holds the air cleaner assembly to the radiator core support.
2. Install the curved support bracket on lower portion of the AirMax housing. Install the bent angle bracket to upper portion of AirMax housing. Use the supplied hardware to secure the brackets. Assembly with a 1/4" bolt, flat washer, bracket, housing, flat washer and tighten down with a 1/4" nyloc nut.
3. Install K&N air filter (RU-3700) onto AirMax housing. Guide the AirMax housing into factory air cleaner position. Secure the AirMax assembly to the vehicle with the supplied 6mm bolts, flat washers, lock washers and nuts.
4. Fasten the air inlet hose to AirMax assembly. Double-check the fasteners for proper tightness and align the housing for clearance.



Parts List

- 1 AirMax housing
- 1 K&N air filter (RU-3700)
- 1 curved support bracket
- 1 bent angle support bracket
- 2 1/4x3/4" bolts
- 4 1/4" flat washers
- 2 1/4" nyloc nuts

Any questions call: **Street & Performance Electronics**
304 Smokey Lane North Little Rock, Arkansas 72117
Phone: (501) 945-0354 FAX: (501) 945-0370
www.StreetandPerformanceElectronics.com