

AIRMAX

Installation Instructions

(2000-2006 GM C/K 1500 Silverado 4.3L V-6
2007 GM C/K 1500 Silverado "Classic" 4.3L V-6 Part # 14350)

Important! Read all instructions before you begin installation.

1. Disconnect the harness plug from Mass Air-Flow (MAF) sensor. Loosen clamps at the MAF, air filter assembly, and the throttle body air inlet. Remove the air inlet tube, MAF, and air filter assembly from vehicle.
2. Loosen and remove the two air filter tray bolts closest to the engine. Install the AirMax housing onto air filter tray and attach with the OE bolts. Attach the MAF to the AirMax housing with the 4-inch coupler and clamps, loosely.
3. Attach the AirMax elbow to the air inlet with the 3.5" bump coupler and clamps, loosely. Join the MAF to AirMax elbow with remaining 3.5" straight coupler and clamps. Align the elbow as to have clearance around the oil dipstick. Once, the assembly is joined, tighten all clamps firmly as to seal off any air leaks.
4. Install K&N air filter (RF-1015) to AirMax housing.
DO NOT OVER TIGHTEN, AS THIS WILL DEFORM THE FILTER AND IS NOT WARRENTIED BY STREET & PERFORMANCE ELECTRONICS OR K & N FILTERS.
5. Reconnect the MAF harness plug.



Parts List

- 1 AirMax housing
- 1 AirMax elbow
- 1 K&N air filter (RF-1015)
- 1 3.5" bump coupler and clamps
- 1 3.5": straight coupler and clamps
- 1 4.0" straight coupler and clamps

Any questions call: **Street & Performance Electronics**
304 Smokey Lane North Little Rock, Arkansas 72117
Phone: (501) 945-0354 FAX: (501) 945-0370
www.StreetandPerformanceElectronics.com