

# AIRMAX

## Installation Instructions

(2007-2008 Chevrolet Silverado 4.8/5.3/6.0L

2007-2008 Chevrolet Tahoe 5.3/6.0L VORTEC

2007-2008 GMC Sierra 4.8/5.3/6.0L

2007-2008 GMC Yukon/Denali 5.3/6.0L VORTEC Part #15305)

### Important! Read all instructions before you begin installation.

1. Remove engine sight cover. Disconnect Mass Air-Flow (MAF) sensor. Disconnect PCV vent hose from valve cover. Loosen and remove OE air intake assembly.
2. Assemble two locating studs to AirMAX housing, using 5/16" stud, two flat washers and nyloc nut in each slot of housing.
3. Place the AirMax filter housing in the OE location. Align the studs with the two rubber sockets in the assembly tray.
4. Remove the MAF and rubber coupler from OE air intake assembly. Install the coupler and 1/2" nipple onto the AirMax plenum. Using gentle pressure slide the plenum onto the throttle body.
5. Place the 3.5" coupler onto the MAF and plenum. Next, place the 4.0" coupler onto the AirMax housing. Tighten all clamps to ensure a solid seal. Install 1/2" vent hose from valve cover to plenum nipple. Install K&N filter (RF-1015) and tighten clamp to secure the filter to the housing.

**DO NOT OVER TIGHTEN FILTER CLAMP, AS THIS WILL DEFORM OR DESTROY THE FILTER AND IS NOT WARRENTIED BY STREET & PERFORMANCE ELECTRONICS OR K & N FILTERS.**

6. Lastly, tighten the plenum to throttle body clamp. Hand-tighten the clamp enough as **NOT** to break the plenum, but seal the throttle body. Hook up MAF harness plug. Install the engine sight cover.



### Parts List

- 1 AIRMAX housing assembly
- 1 AIRMAX plenum
- 1 K&N air filter (RF-1015)
- 1 3.5" coupler/clamps
- 1 4.0" coupler/clamps
- 2 5/16" studs
- 4 5/16" flat washers
- 2 5/16" nyloc nuts
- 1 1/2" nipple and clamp
- 12" 1/2" hose

Any questions call: **Street & Performance Electronics**  
**304 Smokey Lane North Little Rock, Arkansas 72117**  
Phone: (501) 945-0354 FAX: (501) 945-0370  
[www.StreetandPerformanceElectronics.com](http://www.StreetandPerformanceElectronics.com)