

# AIRMAX

## Installation Instructions

(2001-03 Chevrolet C/K-2500/3500 8.1L Part # 18100)

### **Important! Read all instructions before you begin installation.**

1. Loosen clamp from inlet tube to air cleaner assembly. Remove air inlet tube from air cleaner assembly. Remove air filter cover from air cleaner assembly. Lift remaining air cleaner housing from vehicle.
2. Remove the 10mm bolts from air cleaner tray. Remove air cleaner tray.
3. Install AirMax housing into vehicle. Align housing mounting tabs with corresponding holes in air cleaner tray area. Bolt housing to the tray mount utilizing the OE bolts. Torque to 10 ft/lb.
4. Install K&N filter (RD-1450) to AirMax housing.
5. Install inlet tube to AirMax housing. Tighten air inlet clamp.



### **Parts List**

- 1 AirMax housing
- 1 K&N air filter (RD-1450)
- 1 4" coupler/clamp

Any questions call: **Street & Performance Electronics**  
**304 Smokey Lane North Little Rock, Arkansas 72117**  
Phone: (501) 945-0354 FAX: (501) 945-0370  
[www.StreetandPerformanceElectronics.com](http://www.StreetandPerformanceElectronics.com)