

AIRMAX

Installation Instructions

(1997-2003 Jeep Wrangler (TJ) 2.5/4.0L Part # 34040)

Important! Read all instructions before you begin installation.

1. Remove the 13mm bolt on front of core support rod.
2. Loosen air inlet pipe clamp from OE air filter box.
3. Remove 3 10mm nuts from underneath of fender that holds OE air filter box.
4. Lift air filter box from vehicle.
5. Install AirMax filter housing, using 2 6mmx25mm bolts, on fender. Tighten OE 10mm nuts to hold AirMax housing to fender.
6. Install air filter (RU-2820) onto AirMax filter housing.
DO NOT OVER TIGHTEN, AS THIS WILL DEFORM THE FILTER AND IS NOT WARRENTIED BY STREET & PERFORMANCE ELECTRONICS OR K & N FILTERS.
7. Install 13mm bolt on front core support rod.
8. Tighten air inlet pipe clamp onto AirMax housing.



Parts List

- 1 AirMax filter housing
- 1 K&N air filter (RU-2820)
- 2 6mmx25mm bolts

Any questions call: **Street & Performance Electronics**
304 Smokey Lane North Little Rock, Arkansas 72117
Phone: (501) 945-0354 FAX: (501) 945-0370
www.StreetandPerformanceElectronics.com