

# AIRMAX

## Installation Instructions

(2003-2008 Dodge Ram 1500/3500 5.7 Hemi V-8 Part # 35700)

### **Important! Read all instructions before you begin installation.**

1. Loosen and remove air inlet tube on the filter housing and inlet muffler.
2. 2004 models have to remove crankcase breather hose from airbox assembly. Lift and remove air filter assembly from vehicle.
3. Remove three of the four rubber grommets from mounting tabs of air filter assembly.
4. Transfer the rubber grommets to the mounting tabs on the AirMax housing.
5. Install AirMax housing onto OE mounting pegs.
6. Install air inlet tube. Tighten clamps to secure hose to AirMax housing and muffler.
7. Install air filter (K&N RE-0920).

**DO NOT OVER TIGHTEN, AS THIS WILL DEFORM THE FILTER AND IS NOT WARRENTIED BY STREET & PERFORMANCE ELECTRONICS OR K & N FILTERS.**

8. 2004 models must attach crankcase hose to AirMax housing. (Note: if you are installing a Helix Power Tower PLUS, install the crankcase hose to 90° power tube and cap off the AirMax housing nipple.)



### **Parts List**

- 1 AirMax housing
- 1 K&N air filter (RE-0920)
- 1 Rubber cap

Any questions call: **Street & Performance Electronics**  
**304 Smokey Lane North Little Rock, Arkansas 72117**  
**Phone: (501) 945-0354 FAX: (501) 945-0370**  
**[www.StreetandPerformanceElectronics.com](http://www.StreetandPerformanceElectronics.com)**