

AIRMAX

Installation Instructions

(2004-2005 Dodge Durango 5.7 Hemi V-8 Part # 35715)

Important! Read all instructions before you begin installation.

1. Loosen and remove air inlet tube on the filter housing and inlet muffler. Remove crankcase breather hose from airbox assembly. Unbolt housing from radiator support and fender. Lift and remove air filter assembly from vehicle.
2. Install AirMax housing into the OE position. Assemble the mounting tab to AirMax housing and bolt assembly to radiator support and fender.
3. Install air filter (K&N RE-0920).

DO NOT OVER TIGHTEN, AS THIS WILL DEFORM THE FILTER AND IS NOT WARRENTIED BY STREET & PERFORMANCE ELECTRONICS OR K & N FILTERS.

4. Install new crankcase hose from oil filler neck to AirMax housing. Route the hose to avoid fan.



Parts List

- 1 AirMax housing
- 1 K&N air filter (RE-0920)
- 1 Bracket
- 2 1/4" bolts
- 2 1/4" loc-nuts
- 4 1/4" flat washers
- 33" 5/8" hose

Any questions call: **Street & Performance Electronics**
304 Smokey Lane North Little Rock, Arkansas 72117
Phone: (501) 945-0354 FAX: (501) 945-0370
www.StreetandPerformanceElectronics.com