

AIRMAX

Installation Instructions

(2002-2005 Dodge Ram 2500/3500 8.0L V-10 Part # 38105)

Important! Read all instructions before you begin installation.

1. Loosen and remove air inlet tube on the filter housing and inlet muffler.
2. Lift and remove air filter assembly from vehicle.
3. Remove three of the four rubber grommets from mounting tabs of air filter assembly.
4. Transfer the rubber grommets to the mounting tabs on the AirMax housing.
5. Install AirMax housing onto OE mounting pegs.
6. Install air inlet tube. Tighten clamps to secure hose to AirMax housing and muffler.
7. Install air filter (K&N RU-1785). On 2004 and newer models will require the PCV hose attach on nipple of housing, On 2002-2003, a rubber end cap must be placed on the nipple to prevent air contamination.

DO NOT OVER TIGHTEN, AS THIS WILL DEFORM THE FILTER AND IS NOT WARRENTIED BY STREET & PERFORMANCE ELECTRONICS OR K & N FILTERS.



Parts List

- 1 AirMax housing
- 1 K&N air filter (RU-1785)
- 1 3/4" Rubber cap

Any questions call: **Street & Performance Electronics**
304 Smokey Lane North Little Rock, Arkansas 72117
Phone: (501) 945-0354 FAX: (501) 945-0370
www.StreetandPerformanceElectronics.com