

AIRMAX

Installation Instructions

(2003-2005 Dodge Ram SRT10 8.3L V-10 Part # 38300)

Important! Read all instructions before you begin installation.

1. Loosen and remove air inlet tube from air filter assembly. Unbolt 10mm nut from radiator core support. Remove PCV vent from air filter assembly. Remove air filter assembly lid and air filter. Remove air filter housing from vehicle.
2. Remove bolt holding electric fan shroud to radiator (passenger-side). This will be reinstalled in a later step.
3. Assemble the 3/8" studs to the AirMax housing. Use the studs four 5/16" flat washers and nyloc nuts.
4. Lubricate the rubber locating grommets (WD-40 works well). Lay the AirMax housing in place of the OE air filter housing in the vehicle. Loosely assemble the lower intake tract with the remaining 5/16" bolts, flat washers and nyloc nuts. Attach the bent bracket to the housing with the 1/4" bolt, washers and nyloc nut. Attach the bent bracket to the radiator fan shroud with original bolt. Tighten all nuts and bolts of the AirMax housing.
5. Install K&N filter (RD-1450) and tighten clamp to secure the filter to the housing.
DO NOT OVER TIGHTEN, AS THIS WILL DEFORM THE FILTER AND IS NOT WARRENTIED BY STREET & PERFORMANCE ELECTRONICS OR K & N FILTERS.
6. Install the AirMax housing into the rubber locating grommets.
7. Attach the PCV vent hose to AirMax housing. Attach and tighten the air inlet tube to AirMax housing.
8. (Optional) Testing has found that removing the passenger-side grille insert can aid in more power and performance.



Parts List

- 1 AirMax housing
- 1 K&N air filter (RD-1450)
- 1 AirMax inlet tract tray
- 1 1/4" x 3/4" bolt
- 2 3/8" studs
- 4 5/16 x 3/4" bolts
- 2 1/4" flat washers
- 12 5/16" flat washers
- 1 1/4" nyloc nut
- 6 5/16" nyloc nuts

Any questions call: **Street & Performance Electronics**
304 Smokey Lane North Little Rock, Arkansas 72117
Phone: (501) 945-0354 FAX: (501) 945-0370
www.StreetandPerformanceElectronics.com