



304 Smokey Lane North Little Rock, Arkansas 72117 Phone: (501) 945-0354 FAX: (501) 945-0370

Helix Power Tower PLUS **Installation Instructions**

(1995-1999 Dodge Neon 2.0L {2-bolt throttle body} SOHC Part #20035)

Important! Read all instructions before you begin installation.

1. Unclamp and remove air inlet from throttle body. Remove throttle cables throttle body.
2. Remove two bolts holding the stabilizer bracket on throttle body. Remove two bolts that secure throttle body to intake manifold.
3. Install new gasket, Helix Power Tower PLUS, another gasket and throttle body onto intake manifold using supplied longer bolts. Torque to 10 ft/lb. Install new stabilizer bracket to throttle body using the 3/4" spacer and longer bolt provided. Install lower 1" spacer and original bolt at the transmission.
4. Reinstall throttle cables to throttle body. Install air inlet assembly on the throttle body. Tighten clamp to throttle body.



Parts List

- 1 Helix Power Tower PLUS
- 2 Gaskets
- 2 8mmx80mm bolts
- 2 8mm washers
- 1 6mmx25mm bolt
- 1 6mm washer
- 1 1" spacer (8mm hole)
- 1 3/4" spacer (8mm hole)
- 1 Bracket