



304 Smokey Lane North Little Rock, Arkansas 72117 Phone: (501) 945-0354 FAX: (501) 945-0370

Helix Power Tower PLUS **Installation Instructions**

(1996-1998 Ford Mustang 3.8L V-6 Part #38005)

Important! Read all instructions before you begin installation.

1. Unclamp and remove air inlet hose from throttle body. Disconnect throttle linkage and return spring from throttle body. Loosen and remove 4 throttle body nuts from throttle body. Remove last throttle body bolt from under-side of throttle body. Remove throttle body from intake manifold. Remove the throttle body retaining studs from the intake manifold. Remove throttle body gasket from throttle body.
2. Install a gasket, Helix Power Tower PLUS (engraved 30005 towards throttle body) and last gasket onto intake manifold. Attach throttle body to intake with the four longer bolts and washers provided. Align and attach the sensor bracket to throttle body bolt.
3. Remove throttle cable to bracket bolt. Bolt 3/4" spacer and washer in place of removed bolt. Install 6mm nut on the backside of bracket to secure the cable.
4. Reinstall throttle linkage and return spring to throttle body. Install and clamp air inlet hose to throttle body.



Parts List

- 1 Helix Power Tower PLUS
- 2 Gaskets
- 4 8mmx50mm bolts
- 4 8mm lock washers
- 1 3/4" spacer
- 1 6mmx35mm bolt
- 1 6mm washer
- 1 6mm nut