



304 Smokey Lane North Little Rock, Arkansas 72117 Phone: (501) 945-0354 FAX: (501) 945-0370
www.StreetandPerformanceElectronics.com

Helix Power Tower PLUS Installation Instructions

(2007-2008 Cadillac Escalade 6.0/6.2L VORTEC
2007-2008 Chevrolet Silverado 4.8/5.3/6.0/6.2L
2007-2008 Chevrolet Tahoe 5.3/6.0/6.2L VORTEC
2007-2008 GMC Sierra 4.8/5.3/6.0/6.2L
2007-2008 GMC Yukon/Denali 5.3/6.0/6.2L VORTEC Part #53020)

Important! Read all instructions before you begin installation.

1. Remove engine sight cover. Disconnect PCV hose from air inlet tube. Loosen and remove air inlet tube from Mass Air-Flow sensor (MAF) and throttle body.
If you have an aftermarket air intake system you might have to remove it completely to access the throttle body.
2. Remove the TAC harness from throttle body. Loosen and remove the retaining bolts and nuts from throttle body. Remove the studs from the intake manifold using a 6-point 4mm socket.
3. Install the Helix Power Tower PLUS between the intake manifold and throttle body assembly (engraving facing the throttle body). Now slip the supplied gasket in between the Power Tower PLUS and throttle body assembly. Fasten the throttle body with the supplied longer bolts and washers. Tighten the bolts to 10 Nm (89 lb/in).
4. Remove air inlet anchor from top of manifold, install one-inch extension with countersunk screw and reinstall air inlet anchor into the extension (Not necessary if you have an aftermarket intake installed). Reconnect TAC wire harness.
5. Reinstall air inlet tube and PCV vent hose. Reinstall engine sight cover.
If using an aftermarket air intake you might have to trim the air inlet to accommodate the spacer the Helix Power Tower PLUS needs for installation.



Parts List

- 1 Helix Power Tower Plus
- 1 Gasket
- 4 6mm x 70mm bolts
- 1 6mm countersunk screw
- 4 6mm lock washers
- 4 6mm flat washers
- 1 6mm one-inch extension