



Street & Performance Electronics
304 Smokey Lane North Little Rock, Arkansas 72117
Phone: (501) 945-0354 FAX: (501) 945-0370
www.StreetandPerformanceElectronics.com

Helix Power Tower PLUS Installation Instructions

(2006-2009 Chrysler 300C STR8 6.1L "HEMI"
2006-2009 Dodge Charger SRT8 6.1L "HEMI"
2006-2008 Dodge Magnum SRT8 6.1L "HEMI" Part #61025)

Important! Read all instructions before you begin installation.

1. Disconnect the Intake Air Temperature (IAT) sensor on air inlet tube. Loosen and remove air inlet tube.
If you have an aftermarket air intake system, you may have to remove it completely to access the throttle body.
2. Disconnect the Fly-By-Wire harness from throttle body. Loosen and remove throttle body bolts.
3. Insert Helix Power Tower Plus (HEMI engraved side towards throttle body) and gasket in between the throttle body spacer and throttle body. Using the washers and longer bolts provided in kit, secure the throttle body to intake manifold. Tighten the bolts to 10 Nm (89 lb/in).
4. Reconnect throttle body FBW harness to throttle body.
5. Install air inlet tube onto throttle body and air cleaner assembly. Reconnect the IAT sensor.
If you have an aftermarket air intake system, you may have to adjust or trim the intake system for the throttle body's new position.



Parts List

- 1 Helix Power Tower Plus
- 1 Gasket
- 4 6mm x 70mm bolts
- 4 6mm lock washers
- 4 6mm flat washers

ASK ABOUT OUR AIRMAX AIR INTAKE
FOR EVEN MORE HORSEPOWER!