



304 Smokey Lane North Little Rock, Arkansas 72117 Phone: (501) 945-0354 FAX: (501) 945-0370
www.StreetandPerformanceElectronics.com

Helix Power Tower **PLUS** Installation Instructions

(1999-2000 Nissan Frontier/Pathfinder/Xterra 3.3L V-6 Part #94335)

Important! Read all instructions before you begin installation.

1. Loosen and remove air inlet tube from throttle body.
2. Loosen and remove throttle linkage from intake manifold.
3. Loosen and remove four bolt-holding throttle body to intake manifold. Remove and clean gasket and gasket surfaces.
4. Install a gasket, the Helix Power Tower Plus (engraved side towards the throttle body), another gasket to the intake manifold. Attach this assembly with the longer bolts and washers provided in the kit. Tighten the bolts to 89 lb/in.
5. Attach the included throttle extender bracket to the intake manifold using the supplied 6mm countersunk screws. Now, attach your original throttle bracket to the installed throttle extender bracket.
6. Install air inlet tube to throttle body.

Parts List

1 Helix Power Tower PLUS
2 Gaskets
4 8mm x 60mm bolts
4 8mm flat washers
1 Throttle extender bracket
2 6mm countersunk screws