



Street & Performance Electronics
304 Smokey Lane
North Little Rock, Arkansas 72117
Phone: (501) 945-0354 FAX: (501) 945-0370
www.StreetandPerformanceElectronics.com

Smart-Mount

Uni-Clamp Universal Frame Line Clamp
Installation Instructions
(Part #700500)

Important!
Read all instructions
before you begin
installation.

These items will be needed for a proper installation:

Assorted Drills 3/16" Hex Wrench Micrometer or Measuring Calipers
Drill Press or a way to drill a straight hole in 3/4" aluminum

1. Measure the overall diameter of lines to be mounted. If insulating with a rubber bushings or sleeves, please add this dimension to your overall diameter.
2. Fully tighten cap bolts on Uni-Clamp with a 3/16" hex wrench.
3. Find appropriate drill for each diameter of line. Align and mark the centers of each line on the parting line of the cap and base of the Uni-Clamp.
4. Drill marked holes on parting line of the Uni-Clamp with a drill press.
5. Loosen and remove the cap bolts of the Uni-Clamp.
6. Attach base of Uni-Clamp in appropriate locations on frame using either sheet metal screws or machine screws.
(Note: the Uni-Clamp base attachment holes are 1.4250" on center)
7. Place lines into Uni-Clamp base, align cap on base, and bolt cap to base with the 1/4" x 20 hardware. Tighten to a snug tension and plus a 1/4-turn.

