

AIRMAX

Installation Instructions

(2005-2006 Toyota Tacoma 4.0L V-6 Part # 57405)

Important! Read all instructions before you begin installation.

1. Loosen and remove engine sight cover.
2. Disconnect the Mass Air-Flow (MAF) sensor harness. Loosen and remove MAF sensor. Loosen the clamp at the throttle body. Loosen and remove air filter housing and assembly from vehicle.
3. Assemble the MAF sensor to AirMax tube with supplied screws. Connect the tube to the throttle body using the 3" coupler and clamps.
4. Assemble the bracket to the AirMax housing using the 1/4" nuts, bolts and washers. Install AirMax housing into vehicle. Attach the housing to the tube using the 3" Hump coupler and clamps. Attach the housing to the mounting hole with the supplied bolt and washer.
5. Attach supplied hose to the fuel pressure regulator and supplied nipple. Install nipple into grommet on tube.
6. Install K&N filter (RU-2820) and tighten clamp to secure the filter to the housing.
DO NOT OVER TIGHTEN, AS THIS WILL DEFORM OR DESTROY THE FILTER AND IS NOT WARRENTIED BY STREET & PERFORMANCE ELECTRONICS OR K & N FILTERS.
7. Reconnect the MAF sensor harness. You should double check coupler/clamp tightness and alignment. Reinstall engine sight cover.



Part List

- 1 AirMax Housing
- 1 AirMax MAF tube
- 1 Housing bracket
- 1 K&N air filter (RU-2820)
- 1 3" coupler w/clamps
- 1 3" Hump coupler w/clamps
- 1 8-32 x 1/4 screw
- 1 8-32 x 3/8 screw
- 2 1/4 x 3/4 bolts
- 1 8mm x 30mm bolt
- 4 1/4 flat washers
- 1 8mm flat washer
- 2 1/4 nyloc nuts
- 1 3/16" vacuum nipple w/grommet
- 1 vacuum hose (5/32 x 20)

Any questions call: Street & Performance Electronics
304 Smokey Lane North Little Rock, Arkansas 72117
Phone: (501) 945-0354 FAX: (501) 945-0370
www.StreetandPerformanceElectronics.com